

Calibration Columns "Pressure Rated"

Calibration Columns allowing quick measurement to ensure accurate flow rates.

Used when commissioning and maintaining pumps to ensure accurate flow rates, these Calibration Columns have:

- PVC calibration columns other materials and styles are available.
- Van-Stone Style Flange Connections to minimise potential leak points and simplify installation and maintenance. Flanges are standard ANSI 150#.
- Scale in metric units read the volume in mL drawn during the measured time and immediately you have a dose rate.
- Capacities from 100 mL (6 L/H) to 20 L (1200 L/H).
- Tube is of Schedule 40 uPVC, flanges are Schedule 80 Grey uPVC.



H2O Rx PO Box 748 Lane Cove NSW 1595

Web: www.h2orx.com.au

Phone: 0409 784 236

RADIOACTIVE

Email: info@h2orx.com.au

Calibration Columns "Pressure Rated"

Part Number	Pressure Rating kPa*	Pump Rate (L/H)	Volume (L)	Scale Divisions (mL)	Overall Height (mm)	Overall Diameter (mm)	Process Connection ANSI 150# Flange
CP-100-F	1000	6	0.10	1	300	108	DN25
CP-250-F	1000	15	0.25	1	600	108	DN25
CP-500-F	750	30	0.50	5	425	152	DN50
CP-1000-F	750	60	1.00	5	675	152	DN50
CP-2000-F	750	120	2.00	10	700	191	DN80
CP-4000-F	750	240	4.00	10	775	229	DN100
CP-10000-F	500	600	10.00	100	700	343	DN200
CP-20000-F	500	1200	20.00	100	1025	343	DN200

^{*} Pressures are quoted at 20 degC with water.

Operation is simple:

- 1. Stop the dosing pump.
- 2. Open Valve 'A' until the calibration column fills via gravity.
- 3. Close Valve 'B'.
- 4. Run the dosing pump for one minute.
- 5. Using a stopwatch time a 1 minute draw down and note the volume (mL)
- 6. Multiply this volume by 60 and divide by 1000 to convert to L/H dose rate.
- 7. Close Valve 'A' and open Valve 'B'.

